

INSTRUCTIONS FOR USE

1. Remove all the packaging and labels before use.
2. Wash the pan in warm soapy water to remove any traces of dust. Dry it and wipe it over with a dash of oil, removing any excess with normal kitchen paper (this should be done periodically to keep the pan in perfect shape).
3. Make sure the heating element matches the size of the pan and does not extend beyond the edge; moderate heat is always sufficient.
4. FINEGRES coating resists high temperatures, so it will not be subject to alteration (even so, it is best never to overheat it when empty). Never leave a pan unattended on or in the cooker. Make sure that fatty foods never burn. Let the pan cool down before cleaning it.
5. A dash of oil is recommended when dry-frying.
6. If burnt, some fatty foods (sausages, bacon, etc.) may leave a slight stain. To remove this, fill the pan with hot water and some detergent, and then rub clean with a soft cloth. In the case of more persistent stains, heat up some cooking oil in the pan, clean it with kitchen paper and then wash it with detergent and water. In any case, slight discolorations cause no harm to the pan.
7. Avoid any action that might scratch or damage the surface. To ensure ideal performance, do not use sharp metal implements or cut food in the pan.
8. When using cooking pans on glass-ceramic plates, make sure they do not slip.
9. Items with FINEGRES coating can easily be washed by hand using a non-abrasive sponge. When using a dishwasher, rinse when cold before placing them in the machine. Note however that the hardness of the water and the aggressiveness of the detergents used in dishwashers may reduce the properties of the interior coating.
10. To ensure prolonged use, handle with care at all times, making sure not to scratch the surface.
11. Do not keep kitchenware designed for use on induction plates on the heat for more than 1 minute when empty.
12. To avoid burns, the use of pot-holders is always recommended when handling articles with metal grips and handles.

GUARANTEE 5 YEARS

MONETA guarantees this item against all defects in material and workmanship. This guarantee does not cover damage caused by accidents or failure to observe the instructions for use.